

# DOG GUARD<sup>®</sup>

## OUT OF SIGHT FENCING

Dog Guard of Southwest Virginia<sup>®</sup>

### T-4 Outdoor Transmitter

#### Features

The T-4 transmitter features user friendly lights and audible signals to let you know the transmitter is working properly, and when there is a problem with the signal field.



- The T-4 transmitter has two frequency settings to accommodate side by side installations, and can be used on any size yard up to 50 acres.
- When the T-4 transmitter is set in the encoded mode, an ID code makes the system immune to all interference from stray signals, and provides dual zones, or signal fields. In the first signal field, the pet receives a warning level stimulus that has been preset on the front of the T-4 transmitter. Its purpose is to warn the pet to turn back. Should the pet enter the second signal field, the receiver will automatically increase to a stronger stimulus.
- The CORRECTION LEVEL ADJUSTMENT, when the encoded mode is activated, provides 32 LEVELS OF STIMULATION TO CHOOSE FROM. This will set the amount of stimulation the pet receives in the first signal field.
- In operation
  - The green **POWER** light is on all the time when the system is powered.
  - The red **LOOP** light is on when the loop is intact. If there is a line break, the light will go off. An audible alarm will sound from inside the T-4 transmitter alerting you to the problem.
  - The yellow **FAULT** light comes on if the T-4 transmitter encounters a power surge or lightning strike. An audible alarm will sound from inside the T-4 transmitter alerting you to the problem.
- The T-4 transmitter has a life time warranty.



The **TERMINAL BLOCK** is where the loop wires and ground wire are attached to the T-4 transmitter. It is labeled for easy wire identification.

The **RANGE CONTROL** adjuster is recessed to prevent unwanted tampering. The field range can be easily adjusted by using a small screwdriver.